

## CountEasy CE2.6 New Features

**CountEasy V2.6** includes three new features that make it even more flexible and powerful.

This sheet provides a brief summary of each feature showing how each one can be used:

### 1. NEW DISPLAY LAYOUT

The display now shows the running total in the bottom right hand corner at all times – even when there are items on the hod:

		Nothing on the hod Running Total = £0
		£1.24 on the hod in 1p's Running Total = £1.24
		£1.24 on the hod in 2p's Running Total now = £2.48

The advantage of displaying the Running Total all the time is that it is easier to count to a target value such as a float value

### 2. AUTO SCROLL TOGGLE

Auto scroll can now be switched on and off via either arrow on the button being pressed for longer than 5 seconds. The Auto scroll indication (>) on the right hand side of the display will change to show the auto scroll setting.

This feature is useful when switching between counting a till down (auto scroll is very useful) and counting larger amounts of cash for Banking where Auto Scroll is less useful.

### 3. NOTE / COIN NO SCROLL OPTION

There is now a new 'NO SCROLL' option for each Coin and Note. This setting is accessed via **SetUp Level 2, "NOTE / COIN ENABLE"**

If a note / coin is **ON** it will be selectable via the button and will be included in any auto-scroll sequence.

If a note / coin is **OFF** it will not be selectable via the button and will not appear in the auto-scroll sequence.

If a note / coin is **NO SCROLL** it will be selectable via the button and will not appear in the auto-scroll sequence.

This is useful any coins or notes that are not used very often and therefore are better missed out of the AutoScroll sequence.